



SMOKETIP

INSTRUCTIONS

HOW TO USE Your SmokeTip unit is made up of two pieces - a long white battery and an atomizer cartridge. The battery will be charged when you receive so you can begin to enjoy right out of the box! Remove a cartridge and take off the two end caps. Screw the cartridge onto the battery. For each new cartridge take a long 3-4 second drag followed by a 1-2 second drag to help start the atomizer & prep the liquid - do this a few times for each new cartridge.

When the unit no longer creates a vapor, has a "burnt" taste, gets very warm, or has no flavor it may be time to change the cartridge. You should try to change the battery first, before changing the cartridge (your battery may be low if no vapor is produced). Please use caution because the cartridge can get hot when there is no solution left. Our unique cartridge design prevents leaking BUT if for some reason it does, wash your hands thoroughly.

How Long Does a SmokeTip Cartridge Last? Results will vary depending on the intensity of a person's average inhalation. One SmokeTip Electronic Cigarette atomizer cartridge will last the equivalent of approximately 1.25 packs of cigarettes. Should you experience little or no vapor, ensure that your battery is fully charged and properly attached to the device.

Charging While in use, the LED on the tip of the battery will flash if the battery is low and needs recharging. Plug the wall adapter into the wall and take the white battery and screw it into the USB charger then plug into the wall adapter. The tip of the battery will blink 3 times when plugged in properly. The USB charger may also be used directly into any USB port on your computer. Charging the battery will be 2-3 hours.


Battery or Cartridge Leaks do not touch - place in a plastic bag for replacement. As with any electronic device, prevent it from mixing with metal articles in your pocket, purse or other bags - this will damage the battery and cartridge. We do have carry cases to prevent this issue.

Caution As with any electrical device, this unit should be charged on a fire-resistant surface. A bad connection may increase the risk of overheating and make the unit very hot. For issues please contact us immediately. Do not leave unattended for long periods of time.



XL POD

INSTRUCTIONS



Fully charge the battery before your first use to ensure long battery life.

Changing XL Pods When your pod no longer creates vapor or there is a slight burning taste simply remove the pod and replace. When replacing insert fully with a slight twist to align the interior tabs. Make sure the pod is fully seated into the battery.

Charging when the LED Light on the bottom of your battery is flashing, insert the supplied usb-c charging cord and connect to your choice of power supply (wall adapter, computer). When charging, the led light will remain on and will turn off when charging is complete. As with any electrical device, charge on a stable fire-resistant surface clear of debris. We recommend you only use the charging cords supplied. As with any battery charging device, do not leave unattended for long periods of time.

Battery Safety Never carry any battery in your pocket or other closed area on your body as an additional safety precaution - especially mixed with other items including metal. Always charge batteries on a fireproof surface and make sure there are no flammables within at least 6 feet while unattended. Remove batteries from chargers as soon as you are able when they are fully charged. All our batteries are equipped with over charge and error detecting technology, but if there is physical damage to a battery or charger these safety mechanisms may become inoperable. If your battery becomes significantly wet or suffers physical damage, discontinue use and contact us for an exchange.

Maintenance If your battery is not performing as normal clean the 2 terminals gently inside the opening at the top inside of the battery with rubbing alcohol. If no vapor is being produced at all, and you are sure your pod has liquid and the battery is charged, one of the terminals inside the top of the batteries may be unaligned - you can try to gently move the terminals.



vMyst

INSTRUCTIONS

- 1 On the top of the warmer insert a vTube open side down.
 - 2 Press and hold the power button for 3 seconds. After about 10 seconds the warmer will vibrate letting you know it's ready - you can then take a drag as normal.
-

Using vMyst is very similar to traditional smoking. Drag and use as you would normally. There is no need to keep the button pressed while using, it will stay active for about 4 minutes, about the same time as it takes to smoke a traditional cigarette. If you drag slower than average, or want to take a break, the warmer will automatically turn off. You can continue using a vTube until it is fully consumed - all at once or over time. The unit will vibrate and blink when it's about to turn off. You can still take 1-2 drags after the cycle ends - simply repeat this process as desired.

If there is any damage to the unit, please do not continue to use and contact us as soon as possible. Please see the FAQ on our site for more detailed information. Please contact us anytime on our website by clicking the chat button on the bottom of any page.

Indicator Lights The side led light lets you know how much battery power you have. Green = 75% + Blue = 25%-75% Red = less than 25%.

Charging the fastest charging method (26 minutes from 0% to 100%) is to use the usb charger, plugged into a wall adapter. To use the magnetic charger, plug the micro magnet connector into the port on the bottom of the warmer. Then plug the cord in & magnet-connect to the micro plug. Magnetic charging is very convenient but it is about 1/4 the speed of plugging into the wall so if you want a full charge fast, use the standard USB plug into a wall charger. The red light will blink when low power. You can have the unit plugged in while in use if convenient.

Self Cleaning & Cleaning press the button 5 times consistently and the warmer will enter self cleaning mode. The red light will flash 18 seconds while cleaning. Please do not use or press the button during this time. Every 5 vTubes or so, you can turn the unit upside-down and gently tap to remove any small debris. You can also use the cleaning tools supplied to clean the heating element. Please do this very gently, to prevent any damage to the delicate coil. Please do not disassemble the unit - there is no need to do this to clean.

Follow all battery disposal methods when it's time to discard.